# W-DMX<sup>TM</sup> G6 USER MANUAL

BLACKBOX F-1 BLACKBOX F-2 BLACKBOX R-512

Latest revision: December 2020 www.wirelessdmx.com

WIRELESS SOLUTION MADE IN SWEDEN



W-DMX<sup>™</sup> BlackBox G6 User Manual

Issue date: 2020-12 Edition: 1<sup>st</sup> Edition

Subject to modifications.

All trademarks referenced are trademarks or registered trademarks of their respective owners, whose protected rights are acknowledged.

Copyright © 2020, Wireless Solution Sweden AB

Wireless Solution Sweden AB Majorebergsvägen 2 451 75 Uddevalla Sweden

Tel.: +46 522 511 511

E-Mail: helpdesk@wirelessdmx.com Web: www.wirelessdmx.com

## TABLE OF CONTENTS

1. SAFETY INFORMATION
1.1. ENGLISH
1.2. DEUTSCH
2. YOUR WIRELESS DMX G6 SYSTEM
4. USER INTERFACE
4.1. F-1 and R-512 models
4.2. F-2 MODEL
5. HARDWARE
5.1. F-1 AND R-512 MODELS
5.1.2 CONTENTS INCLUDED
5.2. F-2 MODEL
5.2.2 CONTENTS INCLUDED
6. OPERATION
6.1. BASIC SETUP – LINKING DEVICES
6.2. UNLINKING DEVICES
6.3. LINKING MULTIPLE TRANSMITTERS WITH MULTIPLE RECEIVERS
6.4. Switching FLEX mode
6.5. CHANGING MODE
6.6. W-DMX <sup>™</sup> Configurator app & Bluetooth
6.6.1. Setting PIN code
6.6.2. RESET PIN CODE
6.6.3. TURNING BLUETOOTH ON/OFF
6.7. RDM
6.8. FREQUENCY USAGE
7. UPGRADES AND UPDATES
7.1. WIFI UPGRADE
7.2. CRMX <sup>™</sup> UPGRADE
7.3. FIRMWARE UPDATE
8. TIPS & TRICKS
9. COMPLIANCE INFORMATION
9.1. FCC
9.2. Industry Canada
9.3. CE
9.4. UKCA
17

## 1. Safety information



#### 1.1. English

- 1. Please read these instructions and safety instructions carefully before using this product.
- 2. Keep these instructions for future reference.
- 3. Never plug the product into the mains supply while it is still in its packaging. Never cover during use.
- 4. Only use indoors and in dry spaces, except where otherwise explicitly stated.
- 5. Verify that the product has not been damaged in transport before you make use of it.
- 6. Keep the product out of the reach of animals, children and persons who require supervision.
- 7. This product is intended for professional use only.
- 8. Always place the product on a stable, solid and flat base or safely secure it.
- 9. Do not use the product near hot surfaces or objects.
- 10. The mains cable must be regularly and carefully checked for damage to the cable, the plug and other parts. In the event of damage, the product must not be used until the mains cable has been replaced. If the product needs to be cleaned, the adapter or mains cable must be disconnected from the mains supply.
- 11. Repairs must only be carried out by a qualified person.
- 12. Note that the connected voltage and current corresponding to the sticker on the product.
- 13. Never submerge the product or the mains cable in water or any other liquid, in order to prevent electric shocks, fire, injury and other hazards.
- 14. Never carry the product by the cables and do not put the cord around sharp edges.

#### 1.2. Deutsch

- 1. Bitte lesen Sie diese Hinweise und Sicherheitshinweise sorgfältig durch, bevor Sie dieses Produkt verwenden.
- 2. Bewahren Sie diese Anleitung zum späteren Nachschlagen auf.
- 3. Das Produkt nie anschließen, wenn es sich in der Verpackung befindet- Außerdem darf das Produkt beim betrieb nicht abgedeckt werden.
- 4. Nur in trockenen Innenräumen verwenden sofern nicht ausdrücklich anders angegeben!
- 5. Versichern Sie sich vor der Verwendung, das dieses Produkt beim Transport nicht beschädigt wurde.
- 6. Produkt außerhalb der Reichweite von Kindern, Tieren und zu beaufsichtigenden Personen aufbewahren.
- 7. Dieses Produkt ist nur für den professionellen Gebrauch bestimmt.
- 8. Stellen Sie das Produkt immer auf eine stabile, feste und flache Fläche auf.
- 9. Verwenden Sie das Produkt nicht in der Nähe von warmen Oberflächen oder Objekten.
- 10. Das Netzkabel muss regelmäßig und sorgfältig auf Schäden am Kabel, Stecker und anderen Teilen kontrolliert werden. Bei einem Schaden darf das Produkt erst wiederverwendet werden, wenn das Netzkabel repariert/ersetzt ist. Wenn das Produkt gereinigt werden soll, muss das Netzkabel vom Stromnetz getrennt werden.
- 11. Eventuell anfallende Reparaturen müssen von einer qualifizierten Person ausgeführt werden.
- 12. Beachten Sie, dass die angeschlossene Spannung und Strom dem entsprechen, was auf dem Typenschild angegeben ist.
- 13. Tauchen Sie das Produkt oder das Anschlusskabel niemals in Wasser oder in andere Flüssigkeiten ein, um einen Stromschlag, Brand, Verletzungen oder andere Gefahren zu vermeiden.
- 14. Das Produkt nicht am Netzkabel tragen und das Netzkabel nicht um scharfe Kanten legen.

## 2. Your Wireless DMX G6 System

Welcome to the Wireless DMX family! We hope you enjoy your brand-new devices – Wireless Solution is the industry's leading system for transmitting and receiving DMX signals reliably, and we thrive on avid users like you who use our products. We appreciate all your constructive feedback!

Before you use, you must know: there are two main operating modes:

- **[TX]** Transmitter (to transmit DMX data as wireless signals)
- [RX] Receiver (to receive wireless signals and output as DMX)

Most our products are transceivers, meaning they can transmit or receive W-DMX<sup>™</sup> signals, depending on how you set them up:

Product	TX	RX	RDM	WiFi
BlackBox G6 F-1 G5	<ul> <li>Image: A set of the set of the</li></ul>	<ul> <li>Image: A set of the set of the</li></ul>	✓	$(\checkmark^1)$
BlackBox G6 F-2 G5	<ul> <li>Image: A second s</li></ul>	<ul> <li>✓</li> </ul>	✓	$(\checkmark^2)$
BlackBox G6 R-512		✓	✓	

All G6 products are backward compatible to Generation 3. In order to operate in compatibility mode, please refer to 6.5 in this manual. By using the product in a compatibility mode, you will lose some of the features present in other modes. Please refer to our helpdesk service if you want to find more about which features you won't be able to use in compatibility mode.

W-DMX<sup>™</sup> G6 is compatible with CRMX<sup>™</sup> protocol from LumenRadio AB. To use CRMX<sup>™</sup> in your W-DMX<sup>™</sup> G6 product you will need to install the appropriate license on your device. This can be done using the W-DMX<sup>™</sup> Configurator App.

You may find W-DMX<sup>™</sup> being used by several lighting manufacturers – this protocol, if specifically named "W-DMX<sup>™</sup>" will work in an identical way as a branded Wireless Solution product, and it is therefore compatible with our transmitters and receivers.

<sup>&</sup>lt;sup>1</sup> Available as option, sold separately

<sup>&</sup>lt;sup>2</sup> Available as option, sold separately

## 3. The W-DMX<sup>™</sup> Technology

W-DMX<sup>™</sup> is engineered by Wireless Solution Sweden to provide the same quality, reliability and performance as any wired DMX link. The technology allows you to establish point-to-point links, point-to-multipoint and multipoint-to-multipoint:



W-DMX<sup>™</sup> is unique in its use of advanced radio technologies that are also used in mobile phones and military communication.

Rather than using fixed frequency channels, W-DMX<sup>™</sup> uses Adaptive Frequency Hopping technology to continually check the radio channels for interferences and to rapidly move operation to clear radio channels. The checks are carried out in combination with another advanced technology: time division multiple access. This technology makes the most efficient use of every visited frequency channel.

### 4. User Interface

Though the interface display appears simple, there is a lot of information you can read back, which will help you properly set up your system and help you understand how your devices are operating.

#### 4.1. F-1 and R-512 models



- 1. BATTERY Not used on the BlackBox series.
- 2. SIGNAL Indicates that the Signal status is showing signal strength.
- **3. SIGNAL STATUS** On a receiver; indicates the received signal quality. On a transmitter; indicates the configured output power.
- 4. TX Device is operating as a transmitter.
- 5. RX Device is operating as a receiver.
- 6. LINK On a transmitter; states it's ready to establish a link.

On a receiver;

- Off: not linked to any transmitter
- On: active link from a transmitter
- Blinking: Linked to a transmitter but link is lost [either the transmitter is outof-range or turned off].
- 7. DMX Indicates whether DMX data is present.
- 8. MODE Indicates the radio mode [See chapter 3.4].
- 9. RDM Flashes when there is RDM traffic activity.
- **10. PWR** States power condition of the device.
- 11. WIFI Indicate WiFi status;
  - Off: No WiFi installed, or WiFi is disabled
  - On: WiFi is enabled and a protocol configured.
  - Blinking slowly: WiFi is enabled, but no protocol is configured.
  - Blinking rapidly: WiFi is enabled and receiving ArtNet or Streaming ACN data.
- 12. Red function button.

#### 4.2. F-2 model



- 1. Red function button Radio A
- 2. TX Device is operating as a transmitter.
- 3. LINK On a transmitter; states it's ready to establish a link.
  - On a receiver;
    - Off: not linked to any transmitter
    - On: active link from a transmitter
    - Blinking: Linked to a transmitter but link is lost [either the transmitter is outof-range or turned off].
- 4. MODE Indicates the radio mode [See chapter 3.4].
- 5. PWR States power condition of the device.
- 6. RX Device is operating as a receiver.
- 7. DMX Indicates whether DMX data is present.
- 8. RDM Flashes when there is RDM traffic activity.
- 9. WIFI Indicate WiFi status;
  - Off: No WiFi installed, or WiFi is disabled
  - On: WiFi is enabled and a protocol configured.
  - Blinking slowly: WiFi is enabled, but no protocol is configured.
  - Blinking rapidly: WiFi is enabled and receiving ArtNet or Streaming ACN data.
- **10. SIGNAL STATUS** On a receiver; indicates the received signal quality. On a transmitter; indicates the configured output power.
- 11. Red function button Radio B

## 5. Hardware

#### 5.1. F-1 and R-512 models



- 1. AC Power Supply connector, powerCON® TRUE1® 90-250V / 50-440 Hz (for other voltage and frequency options, contact manufacturer)
- WiFi antenna NOTE: Option to be purchased separately – contact manufacturer. Not available on R-512 model.
- 3. XLR female 5 pin [DMX out]
- 4. F-1: XLR male 5 pin [DMX in] R-512: XLR female 5 pin [DMX out]
- 5. XLR female 3 pin [DMX out]
- 6. F-1: XLR male 3 pin [DMX in] R-512: XLR female 3 pin [DMX out]
- DC Power Supply Connector, 5.08mm NOTE: 12V DC power supply [Polarity marked on the box] ±20%, reverse polarity protected. Use a UL/ETL class 2 power supply.

#### 5.1.2 Contents included

When you purchase a new BlackBox, the following items are included:

- BlackBox device [F-1 or R-512]
- User Manual
- Antenna adapter [90 Deg]

- 3dBi antenna
- Mounting brackets
- Phoenix DC connector

**Working Temperature:** -10° to 45° Celsius, storage temperature -20° to 50° Celsius. Max. humidity 90% (non-condensing). For working conditions outside this limit, contact manufacturer. **Dimensions:** W x D x H: 260 x 210 x 70 mm [10.2" x 8.3" x 2.8"] | Net: 1 Kg [2.2 lb.] **NOTE:** Power cable is not included.

#### 5.2. F-2 model



- 1. AC Power Supply connector, powerCON® TRUE1® 90-250V / 50-440 Hz (for other voltage and frequency options, contact manufacturer)
- 2. WiFi antenna NOTE: Option to be purchased separately – contact manufacturer. Not available on R-512 model.
- 3. XLR female 5 pin [DMX out Radio A]
- 4. XLR male 5 pin [DMX in Radio A]
- 5. XLR female 5 pin [DMX out Radio B]
- 6. XLR male 5 pin [DMX in Radio B]
- DC Power Supply Connector, 5.08mm NOTE: 12V DC power supply [Polarity marked on the box] ±20%, reverse polarity protected. Use a UL/ETL class 2 power supply.

#### 5.2.2 Contents included

When you purchase a new BlackBox, the following items are included:

- BlackBox F-2 device
- User Manual
- 2pcs. antenna adapter [90 Deg]
- 2pcs. 3dBi antenna
- Mounting brackets
- Phoenix DC connector

**Working Temperature:** -10° to 45° Celsius, storage temperature -20° to 50° Celsius. Max. humidity 90% (non-condensing). For working conditions outside this limit, contact manufacturer. **Dimensions:** W x D x H: 260 x 210 x 70 mm [10.2" x 8.3" x 2.8"] | Net: 1 Kg [2.2 lb.] **NOTE:** Power cable is not included.

## 6. Operation

All W-DMX<sup>™</sup> G6 devices uses similar user interfaces, however some model-specific differences may apply.

#### 6.1. Basic setup – Linking devices

A basic setup is defined by the link between two devices. This means that, in order to send data from a transmitter to a receiver, it's necessary to link the devices:

Press the red function button, on the transmitter *momentarily* and the *LINK* LED starts flashing.



**NOTE:** All available (currently unlinked) receivers, as long as they are turned on and compatible with the transmitter's radio mode, will pair with this transmitter. The *LINK* LED of each receiver will flash for 5 seconds, and then stay static once linked up.

There is no limit of the number of receivers that can link up with a transmitter – there can be an infinite number of receivers all paired with a single transmitter.

**NOTE:** An F-2 in RX mode will not link RADIO B unless RADIO A is already linked. This is to allow easy linking to different transmitters.

#### 6.2. Unlinking devices

There are two ways to unlink devices – individual unlink, or group unlink:

#### Individual unlink:

Press and hold the red function button, on each receiver that you wish to unlink, <u>for at least 3</u> <u>seconds</u>. The LINK LED will turn off.



#### Group unlink:

Press and hold the red function button on the transmitter <u>for at least 3 seconds</u>. This will unlink all currently powered receivers that are linked to this transmitter.

#### 6.3. Linking multiple transmitters with multiple receivers

When multiple receivers need to be linked up with different transmitters, repeat the process in 6.1., but turn off all receivers you do not wish to pair up. For example:

- If you have 2 transmitters and 10 receivers, pair the first transmitter to 5 receivers, while the last five are turned off.
- After that, turn the last five receivers, and pair them to the second transmitter.

NOTE: This will not affect any receiver that has already been paired up.

#### 6.4. Switching FLEX mode

All units identified as a transceiver can be changed between transmitter or receiver – the units capable to operate in both modes are listed in chapter 2.

FLEX mode determines if the unit is used in transmit mode (TX) or receive mode (RX):

- 1. Press the red function button rapidly 5 times.
- 2. Press and hold the red function button for at least 3 seconds.
- 3. The LINK and DATA LEDs will flash alternating.
- 4. Each time you press the red function button you will step through the available modes, this will be indicated by a flashing *RX* or *TX* LED.
- 5. Press and hold the red function button

#### Changing FLEX mode of an F-2 unit:

In an F-2 unit the FLEX mode works the same as above, however both universes are controlled using the RADIO A red function button.

TX – TX: Both universes operate as transmitters

RX – RX: Both universes operate as receivers

#### 6.5. Changing MODE

There are a few operating modes within all W-DMX<sup>™</sup> products using different generations of the communication protocol. The W-DMX<sup>™</sup> G6 supports several modes to maximize compatibility with different generations of equipment. When operating as an RX the device will automatically switch to the correct mode depending on the mode of the transmitter that is linking to it. The following modes are supported when operating as an RX:

	MODE LED	
G3	Green	
G4	Red	
G4S	Violet	
G5	Amber	
CRMX <sup>3</sup>	White	

<sup>&</sup>lt;sup>3</sup> CRMX mode requires the CRMX option to be installed.

While operating as a TX you can change between modes at any given moment:

- 1. Press the red function button rapidly 3 times.
- 2. Press and hold the red function button for at least 3 seconds.
- 3. Each time you press the red function button you will step through the available modes; this will be indicated by the *MODE* LED.
- 4. Press and hold the red function button to save and exit.

**NOTE:** When operating as TX, some modes are not supported.

**NOTE:** All changes shall be made to the transmitter. It's necessary to re-link all receivers after changing control modes.

#### 6.6. W-DMX<sup>™</sup> Configurator app & Bluetooth

All configuration and operation can be performed from the W-DMX<sup>™</sup> Configurator app that is available from App Store on iOS and Google Play on Android.



W-DMX<sup>™</sup> Configurator app, search for "W-DMX Configurator" on App Store or Google Play.

#### 6.6.1. Setting PIN code

To avoid unauthorized access to W-DMX<sup>™</sup> G6 devices, it is recommended to set a PIN code for your device. This is done from the W-DMX<sup>™</sup> Configurator app.

#### 6.6.2. Reset PIN code

If you have forgotten your PIN code, you can reset it by following the following procedure:

- 1. Press the red function button rapidly 7 times.
- 2. Press and hold the red function button for at least 3 seconds.
- 3. The device will now reboot with the PIN code disabled.

#### 6.6.3. Turning Bluetooth on/off

The *MODE* LED will flash with a blue light every two seconds when Bluetooth is enabled. When Bluetooth is disabled, no blue flashes will appear on the *MODE* LED.

Bluetooth can be switched on or off at any time:

- 1. Press the red function button rapidly 2 times.
- 2. Press and hold the red function button for at least 3 seconds.
- 3. The device will now reboot with the Bluetooth mode toggled.

#### 6.7. RDM

As default, all products come with RDM disabled. To use RDM, this must be enabled from within the W-DMX<sup>™</sup> Configurator app.

23:55		ııl ≎ 🗖				
🗸 Back	SETTINGS	3				
OUTPUT POWER						
MIN	100 MW	МАХ				
FREQUENCY USAGE						
LOWER HALF BAND						
DOWNSTREAM RDM						
10	u 🛛	OFF				
PIN CODE	PIN CODE					
SI	SET/CHANGE PIN CODE					
SAVE SETTINGS						

The changes must be done on the transmitter and on each receiver that needs to do downstream RDM.

#### 6.8. Frequency usage

Sometimes there are cases that require some extra frequency planning. To make this easier for you, the W-DMX<sup>™</sup> Configurator app provides a number of pre-set options for frequency usage;

- Full band
- Lower or upper half
- Lower, mid or upper third

Selecting any of these settings, except for *Full band*, limits the device's frequency hopping so that it leaves the other parts of the bands untouched.

## 7. Upgrades and Updates

Before starting to install any upgrade options, make sure you have updated to the latest firmware version.

#### 7.1. WiFi upgrade

The WiFi upgrade pack comes with detailed instructions on how to install the WiFi module and how to configure it.

The WiFi module supports ArtNet I/II/III with RDM and Streaming ACN.

#### 7.2. CRMX<sup>™</sup> upgrade

CRMX<sup>™</sup> – the radio protocol of LumenRadio's wireless DMX and RDM systems – can be used by your BlackBox G6 units. It requires a software option that can be purchased separately. Install the option using the W-DMX<sup>™</sup> Configurator app.

#### 7.3. Firmware Update

Wireless Solution is committed to developing and improving its wireless technology – this means that we every now and then releases new firmware versions. Sometimes it might be added functionality, but since even the best makes mistakes sometimes – we might release bug fixes also. All G6 products is updateable, either via the W-DMX<sup>™</sup> G6 update cable or – more conveniently – via our W-DMX<sup>™</sup> Configurator App for iOS and Android.

New firmware versions can be found on Wireless Solution's portal at https://my.wirelessdmx.com or will be downloaded automatically in the W-DMX<sup>™</sup> Configurator app.

#### Instructions for installing firmware updates from the app:

- 1. Start the W-DMX Configurator app on your iOS or Android device.
- 2. Click "Connect" and you will be presented with a list of nearby devices. The list is sorted by an approximated distance.
- 3. Click a device in the list and choose "Identify Device" if you are unsure which unit to connect to.
- 4. Click "Connect Device" to connect to the desired device.
- 5. In the main screen of the app, click "Firmware" to automatically update to the latest firmware for your device.



## 8. Tips & tricks

There are several tips and tricks that could make your wireless transmission work better. Here's a few that should be followed:



It's important that all antennas point to the same axis – wireless waves have a radial pattern that should be valued. There are a number of accessories that can help maintaining directionality.



There are limitations to how wireless waves propagate through air. Physical barriers like glass, concrete and walls will limit the transmission range. Always try to have clear line-of-sight between transmitters and receivers.

## 9. Compliance Information

#### 9.1. FCC

#### FCC IDENTIFIER: XRSTIMOMWAN201

#### FCC Information to User

This product does not contain any user serviceable components and is to be used with approved antennas only. Any product changes or modifications will invalidate all applicable regulatory certifications and approvals

#### FCC Guidelines for Human Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### FCC Declaration of Conformity

We Wireless Solution Sweden AB, Majorebergsgatan 2, 451 75 Uddevalla, Sweden, declare under our sole responsibility that this product complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

#### FCC Radio Frequency Interference Warnings & Instructions

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following methods:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an electrical outlet on a circuit different from that which the radio receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Modifications made to the product, unless expressly approved by Wireless Solution Sweden AB, could void the user's right to operate the equipment.

#### 9.2. Industry Canada

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le resent appareil numerique német pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe B prescrites dans le Réglement sur le broullage radioélectrique édicté par le ministére des Communications du Canada.

#### 9.3. CE

This product complies with the Essential Requirements of RED (Radio Equipment Directive) of the European Union (2014/53/EU). This product meets the requirements of relevant conformance standards. A detailed Declaration of Conformity is available upon request from the manufacturer.

#### 9.4. UKCA

This product complies with the relevant statutory requirements in the United Kingdom. This product meets the requirements of relevant conformance standards. A detailed Declaration of Conformity is available for market surveillance upon request from the manufacturer.

## 10. Warranty

Wireless Solution Sweden AB warrants this W-DMX<sup>™</sup> branded hardware product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original end-user purchaser ("Warranty Period").

Products to be returned under warranty must be accompanied by an RMA Authorization Number. Wireless Solution AB does not warrant that the operation of the product will be uninterrupted or error-free. The manufacturer is not responsible for damage arising from failure to follow instructions relating to the product's use.

# helpdesk@wirelessdmx.com

Wireless Solution Sweden AB Majorebergsvägen 2, 451 75 Uddevalla, Sweden